

Corona-Plus QUICK CHANGE CARTRIDGE



Quick Change Cartridge (QC)

The new Open-Design Vetaphone treater stations can all be fitted with the new unique Corona Quick Change Cartridge.

The complete Corona electrode is mounted in a specially designed pull-out/push-in cartridge, enabling quick and extremely easy cleaning or changing of the complete set of electrodes, in a matter of seconds, without the use of tools, and ensuring minimal downtime and increases productivity.

Automatic power disconnection and reconnection is incorporated in the design, as is electrode realignment and air gap-settings.

There is an added bonus where pattern treatment is used, as electrode set-up can take place quickly and easily when the cartridge is out of the station.

The electrode cartridge is available with segment-, profile and ceramic electrodes.

The innovative Quick Change (QC) cartridge is aimed at film lines with widths from 100 mm to up to 2500

mm. Powerful simplicity brought to the open Corona-Plus stations, for a perfect product for the packaging industry.

Features:

- * No tools required for maintenance
- * Specially designed pull-out / push-in cartridge
- * Offline maintenance in a matter of seconds
- * Ceramic electrodes or
- * Profiled or segmented fin electrodes (4-fins/9-fins)
- * High Vetaphone efficiency = Less Downtime

Specified for:

- * TOU 8/9 Single sided treater stations
- * TOW 8/9 Double sided treater stations
- * Treatment widths from 100 mm to up to 2500 mm

